

MAINTENANCE CHART

SAGHPMVNo1

SANTOEMMA GRACE HP


AFTER EVERY USE, ENSURE THAT YOU COMPLETE THE FOLLOWING 5 STEPS

1.

2.



Clean out top recovery tank thoroughly, flush with clean water.




Ensure the blue vacuum filter is clean and dry.

3



Drain solution tank if machine won't be used within the next 7 days. You can suck this into the top tank by removing the cuff from the wand.

4.



Run vacuum for 10 minutes with the top dome removed. This will dry out any moisture that is sitting near the motor.

5.



Always leave clear dome to one side or upside down. This will help the tank not to condensate, consequently extending the life of the vacuum motors.





MAINTENANCE CHART


SANS300MVNo1

SANTOEMMA NS300 WAND


AFTER EVERY USE, ENSURE THAT YOU COMPLETE THE FOLLOWING 3 STEPS



1.




Disconnect wand from hose and turn upside down over a drain. This will empty the wand of water to keep it in good condition when not in use. 2.



Remove jet nozzles and holders, clean out regularly. Replace nozzles when they lose their ability to evenly fan the water spray.

3.



Remove carpet fibres from inside fishtail and stainless steel wand. A bottle brush is very useful for this.

