

MAINTENANCE CHART

NNRS450MVNo1

NUMATIC NRS450

**AFTER EVERY USE, ENSURE
THAT YOU COMPLETE THE
FOLLOWING 4 STEPS**



1.




Check power lead for visual damage, do not use if damaged.

2.



Always wind power cords around cable retainer on rear of handle and top handle.

3.



Always store machine in the position shown. This will prevent damage to the brush/pad drive.

4.



Check brush or pad drive for wear or damage. Replace as necessary.



REPORT ALL DAMAGES AND TECHNICAL ISSUES TO THE SUPERVISOR