

Superpro 700 series

Commercial Back Pack Vacuum Cleaners

Support: +61 8 9479 1444 www.pacvac.com

CAUTION Read the instruction manual before using the machine. Retain for future reference.







This manual applies to the Superpro 700 Series: Superpro 700, Duo 700, Micron 700, Trans 700 and Wispa 700.

Contents

General Safety Instructions.	Page 2
Product Specific Safety Instructions	Page 2
Symbol Definitions.	Page 3
Patents	Page 3
Wear Right	Page 4
Operate Right	Page 5
Work Right	Page 6
Safety and Maintenance Checks	Page 7
Troubleshooting Guide	Page 8
Service Requirements	Page 8
Warranty	Page 9
Superpro 700 Parts Profile	Page 10
Superpro 700 Specifications	Page 11
Superpro duo 700 Parts Profile	Page 12
Superpro duo 700 Specifications	Page 13
Superpro micron 700 Parts Profile	Page 14
Superpro micron 700 Specifications	Page 15
Superpro trans 700 Parts Profile	Page 16
Superpro trans 700 Specifications	Page 17
Superpro wispa 700 Parts Profile	Page 18
Superpro wispa 700 Specifications	Page 19
Superpro 700 Series Harness, Accessories Parts Profile	Page 20
Optional Extras	Page 21



General Safety Instructions

- 1. This manual shall be considered an integral part of the machine and should be carefully looked after for subsequent reference.
- 2. WARNING Read this instruction manual before using this machine and always follow the Safety and Maintenance instructions.
- 3. WARNING Operators shall be adequately instructed on the use of this machine.
- 4. WARNING This machine is not suitable for picking up hazardous dust (Contact Pacvac for specific equipment for this use).
- 5. WARNING Do not allow the power cord to come into contact with rotating brushes of floor tools.
- 6. WARNING Do not use this machine in wet conditions.
- 7. CAUTION This machine is for indoor use only.
- 8. CAUTION This machine shall be stored indoors only.
- 9. Remove the machine from packaging and ensure it and all its accessories and attachments are present and in perfect condition. Contact the place of purchase immediately in the event of any discrepancies.
- 10. The electrical specifications of this machine are noted on the data plate which is located near the power switch. Ensure the specifications correspond to those of the mains power supply in your area. If the machine is without a data plate, contact the place of purchase immediately.
- 11. This machine is intended for commercial use, for example in hotels, schools, hospitals, factories, shops or offices.
- 12. Do not restrict the vacuum cleaner's airflow. Maintain the vacuum cleaner regularly so that all filters and openings are free of dust, lint, hair build-up or anything else which may affect airflow. Refer to the maintenance instructions in the Product & Training Manual.
- 13. If the machine has been dropped, damaged, left outdoors or has been exposed to liquids, return it to your local Authorised Pacvac Service Centre for a safety check.
- 14. Do not use the machine to pick up flammable or combustible liquids, such as petrol etc. and do not use in areas where they may be present.
- 15. Do not vacuum anything that is burning or smoking such as cigarettes or hot ashes.
- 16. Do not vacuum up hard or sharp objects such as glass, nails, screws etc.
- 17. Keep hair, loose clothing, fingers and all parts of the body away from moving parts and openings.
- 18. Keep the machine and power cord away from heated
- 19. Do not unplug the machine while it is turned on. Turn the machine off, turn the power off at the power outlet then unplug by grasping the plug and pulling gently to unplug.

- 20. Do not handle the machine, power cord or plug with wet hands.
- 21. Unplug from power point when not in use, before servicing or before changing filters and attachments.
- 22. Do not pull or carry the machine by the power cord.
- 23. Do not close doors on the power cord and do not pull the cord around sharp edges or corners.
- 24. Regularly check the power cord for damage, such as cuts, abrasions, exposed wiring or aging. If the power cord or plug is damaged, the complete power cord must be replaced by your local Authorised Pacvac Service Centre in order to avoid an electric shock. The power cord should only be replaced with a Pacvac Genuine Spare Part with the same specifications.
- 25. Store in an appropriate place after use to prevent tripping accidents.
- 26. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the machine by a person responsible for their safety. Children should be supervised to ensure that they do not play with this machine.
- 27. Use only the manufacturer's recommended attachments and/or replacement parts.

Product Specific Safety Instructions

- WARNING This machine is intended for the vacuuming of dry dust and/or small debris off dry carpeted or hard floor surfaces in indoor areas only.
- 2. WARNING Do not use the machine without the dust bag and filters in place.
- 3. WARNING Do not place the Superpro duo 700 model on the ground while the machine is turned on. This can result in irreparable damage to the motor.
- 4. WARNING Do not plug the Superpro trans 700 into a power supply other than 110-120V, 400Hz. An alternate power supply can cause irreparable damage to the motor and other electrical components.
- 5. The following models have a "A"-weighted emission sound pressure level (measured at 1.5 meters) of: Superpro 700 - 67 \pm 3dB(A)

Superpro duo 700 - 74 \pm 3dB(A)

Superpro wispa 700 - 66 ± 3 dB(A) normal mode/ 62 ± 3dB(A) wispa mode

Superpro micron $700 - 65 \pm 3$ dB(A)

Superpro trans $700 - 63 \pm 3$ dB(A).

- 6. WARNING Only use the socket outlet on the machine for purposes specified within these instructions.
- 7. This appliance may be fitted with a power socket outlet (excludes wispa 700 model). A power socket outlet is designed for use with applicably approved electric powerhead attachments. Powerhead attachments use rotating brushes to agitate carpet fibres in order to dislodge dust and/or debris. Maximumwattageforsuchattachmentshallnot exceed 200 watts.
- 8. Floor Tool and Attachment Use

Part No. UA908W - Floor Tool is intended for vacuuming of dry dust and debris off floor surfaces.

Part No. KC910 - Dusting Brush is intended for vacuuming of dry dust from blinds and other delicate surfaces.

Part No. KC911 - Crevice Tool is intended for vacuuming of dry dust and debris from crevices.

Part No. KC912 - Upholstery Tool is intended for vacuuming of dry dust from upholstered surfaces.

Symbol Definitions





Meaning of crossed—out wheeled dustbin:
Do not dispose of electrical appliances as unsorted
municipal waste, use separate collection facilities.
Contact your local government for information
regarding the collection systems available.
If electrical appliances are disposed of in landfills
or dumps, hazardous substances can leak into the
groundwater and get into the food chain, damaging
your health and wellbeing.

Europe Only - When replacing old appliances with new ones, the retailer is legally obligated to take back your old appliance for disposals at least free of charge.

^{2.} ((

The CE Mark certifies that a product has met EU consumer safety, health or environmental requirements.

3.

Class II, Double Insulated Appliance.



The Regulatory Compliance Mark (RCM) indicates a device's compliance with all applicable ACMA regulatory arrangements.

5.



Operator's Manual; Operating Instructions



Attention!

Transportation and Storage
 This appliance and attachments should be packed in double wall corrugated cardboard boxes with dimensions of approximately 33cm x 33cm x 54.5cm.
 Stack levels of boxes shall not exceed four units in a vertical position.

RETAIN THESE SAFETY INSTRUCTIONS FOR FURTHER USE.

Patents

The following patents apply: AU Registered Design 326911 EP Registered Design 001617051-0001

Motor Thermostat

IMPORTANT: The motor is equipped with a thermostat. If for any reason, the vacuum cleaner should over-heat, the thermostat will automatically turn the unit off. Should this occur, turn off the switch and unplug the vacuum cleaner from the electrical outlet and conduct safety and maintenance checks. Allow the cleaner to cool for approximately 30 minutes. To re-start, plug into a power point and switch back on.



Wear Right

Step 1:

- Rotate the dome lid to suit left or right handed vacuuming.
- · Loosen the shoulder straps.
- Adjust the length at top of shoulder strap (if required).
- Lift the back pack by one shoulder strap.
- Then slide your free arm into the other strap.



Step 2:

• Tighten the hipband so the machine rests comfortably on your hips.



Step 3:

- Pull down on shoulder straps for a comfortable fit.
- Adjust position and connect chest strap to secure back pack.



Step 4:

• Make sure the harness is resting on your hips.

IMPORTANT TIP:


If the back pack feels heavy or uncomfortable, it is likely you are not wearing it correctly. Contact Pacvac for further advice.



Operate Right

How to vacuum easier and faster with no back strain.

- 1. Stand upright, with the bent hand piece section parallel to the floor.
- 2. Hold the bent hand piece with one hand at a comfortable arm's length.
- 3. Move forward and away from the power point.
- 4. Use easy underarm swinging motion when detail cleaning and short dabs when spot cleaning, always standing upright.
- 5. Once the end of the power cord has been reached and work completed, return to the power point along the cord line and disconnect the power cord from the power point.
- 6. If work is not completed move to the next area, connect power cord to the nearest power point and repeat steps 1 through 6.
- 7. Remove back pack by sliding the one of the straps off the shoulder, while raising the other arm/shoulder to hold strap in place. Slowly lower the shoulder and lower the back pack to the floor, do not drop.
- 8. If work is completed disconnect power cord from power point then wind from the back pack towards the end of the power cord to reduce likelihood of cable twists. In the process check for nicks, cuts, fractures, and knots.





Work Right

LOOK AT THE LAYOUT (refer to the Fishbone Method below)


- Find the most easily located power point. This is your starting location at the fish's head.
 Your turnaround is the 'tail'.
- Check the room layout (position of desks, tables, chairs, fittings etc.)
- Check the condition of the floor how dirty it is on a scale of 1 to 10.

PLAN THE PROCESS

- See in your mind the fishbone method over the entire area or room to be cleaned.
- Decide which areas are to be detail cleaned (the spine), or spot cleaned (the ribs).

CLEAN SMARTER


- · Work away from the power point.
- Work one side of the fishbone towards tail. Then back the other side towards head.
- Work to the plan long strokes for the detail clean area and short dabs for the spot cleans.




Safety and Maintenance Checks



1. Remove, empty and clean dust bag.



2. Remove and tap gently to clean HEPA filter (flat HEPA filter in micron 700).




3. Check all power cords, for cuts, abrasions and exposed wiring.



4. Wind up power cord from machine end.
Store power cord as shown.



Check the floor tool, wand, bent hand piece and hose for any obstructions.



WEEKLY

Remove and clean external motor filter.



NOTE: Any other servicing should be performed by an authorised technician.



Troubleshooting

Caution: Always unplug the back pack before attempting to solve a problem or when servicing.

PROBLEM:	CAUSE:	SOLUTION:
Back Pack not working	Power cord not firmly plugged into power point, short lead, or machine.	Check all plugs and sockets are firmly plugged in.
	Back pack shuts off due to high motor temperature.	Turn main switch off and unplug the back pack. Conduct safety and maintenance checks found in the Product and Training Manual or as per labelling on the machine. After 30 minutes (60 minutes for wispa) the back pack should be ready for use. If not contact the number below for your nearest Authorised Pacvac Service Centre.
	Circuit breaker or RCD has tripped.	Check the machine is in good working order. If OK, reset circuit breaker or RCD. If circuit breaker or RCD trips again contact your nearest Authorised Pacvac Service Centre.
Back Pack has no/poor suction	Hypercone dust bag full.	Remove, empty and clean Hypercone dust bag.
	Hypercone dust bag not installed correctly.	Remove and empty Hypercone dust bag making sure the rubber edging is correctly fitted around the canister.
	Hose not installed correctly.	Reconnect hose and ensure correctly sealed.
	Blockages.	Remove hose, wand and floor tools; remove any blockages.
	Filters blocked.	Clean Hypercone HEPA filter and external motor filter.



Service Requirements

Our products are designed and built to be functional and durable. For information on use and maintenance please read the Product & Training Manual thoroughly.

Should you require servicing contact your nearest authorised Pacvac Service Centre.



+61 8 9479 1444



Warranty

Your Pacvac Pty Ltd (Pacvac) product has been manufactured to meet our highest quality standards. We urge you to take good care of your product and be sure to follow instructions carefully. This will provide you with the best possible performance and lifespan of the product.

The inclusion of the following paragraph is a requirement by Australian Law. It explains that consumers have rights by law regardless of any warranties provided or not by a manufacturer or supplier.

"Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure."


In addition to guarantees under Australian Consumer Law, Pacvac warrants all machines and their components against faulty material and/or workmanship for a period of two years from the date of purchase by the consumer. The following explains conditions and what to do in the event of a claim:

- Pacvac will replace parts determined as faulty however this does not cover reasonable wear through normal use of any consumable parts, such as but not limited to, bags, filters, hoses, power cords, carbon brushes and floor tools etc.
- Warranty does not cover any machine or component that has been altered, abused, neglected, modified, used with non-genuine Pacvac components or has not been used and maintained as indicated in the Product and Training Manual.
- Warranty repairs can only be carried out by an authorised Pacvac Distributor or Service Centre. Visit our website or call Pacvac for your nearest location.
- All reasonable expenses associated with returning goods for a warranty claim are the consumer's responsibility.
- Claims must be made within two years of the date of purchase and proof of purchase must be supplied with the claim.
- To make a claim under warranty, take the product with proof of purchase to the place of purchase.
 In the event the place of purchase does not satisfactorily rectify the matter, please contact Pacvac.



Superpro duo 700 Parts Profile

Product Number: 200812-005A



Quote these part numbers when ordering spare parts

te these part numbers when ordering spare parts	
Part Name	Part No.
Dome lid	KC251
Hypercone paper bag (Packet of 5)	AF101
Hypercone dust bag	KC502HC
Hypercone HEPA filter	KC270
Main vacuum canister	KC252D
Motor gasket	KC253
Motor 240V 1000W 2 stage by-pass	HV1208
Motor gasket	KC253
Toggle latch	KC131
Intermediate noise insulation	PV254
Intermediate housing IEC	KC256IEC
Power inlet C14	KC257IEC3
Power outlet C18	KC257
Switch rocker 12A 250V	VS261
Screw pan plastite 5x20	N/A
Noise insulation motor	PV255
Short lead holder	KC262H
Short lead IEC type 420mm 10A 3c 1mm ²	KC109IEC
(AU, NZ)	
Motor filter cage	KC264
External motor filter	PV259
Screw ST 6x25	N/A
Bottom cap duo	KC258D
Extension cord 18m 10A 3c 1mm ² (AU, NZ)	KC11118
Power Cord:	
UK 18m 10A 3c 1mm ² C13 (UK, SG, IN, AE)	KC108UKIEC
EU 18m 10A 3c 1mm ² C13 (EU)	KC108EUIEC
	Part Name Dome lid Hypercone paper bag (Packet of 5) Hypercone dust bag Hypercone HEPA filter Main vacuum canister Motor gasket Motor 240V 1000W 2 stage by-pass Motor gasket Toggle latch Intermediate noise insulation Intermediate housing IEC Power inlet C14 Power outlet C18 Switch rocker 12A 250V Screw pan plastite 5x20 Noise insulation motor Short lead holder Short lead IEC type 420mm 10A 3c 1mm² (AU, NZ) Motor filter cage External motor filter Screw ST 6x25 Bottom cap duo Extension cord 18m 10A 3c 1mm² (AU, NZ) Power Cord: UK 18m 10A 3c 1mm² C13 (UK, SG, IN, AE)

Specifications

Volts / Frequency: 220-240V~50Hz Motor: 250V 1000W Two Stage By-pass Noise Level: 74dB(A) ± 3dB(A) (at 1.5m) Filtration: 4 stage, HEPA rated filter Volumetric Airflow (per second): 38 litres

Capacity: 5 litres


Weight: 5.3kg (excluding power cord assembly and hose)

Vibration Level: <2.5m/s²

Technical specifications, part numbers and parts profiles are subject to change without notice.



Superpro 700 Series Harness and Accessories Parts Profile



Quote these part numbers when ordering spare parts

Part Name	Part No.
Bolt 5x20	N/A
Nut 5mm nyloc	N/A
Washer 3/16 x 3/4 N/A	
Washer 3/16 x 7/16	N/A
Carrying frame	KC120
Shoulder strap pair	KC121
Cord restraint	KC268
Back support padding	KC263
Hose complete 32mm 1.2m	KC320
Machine end connector 32mm	KC200
Hose cuff hull 32mm	UA914
Hose clip ring 32mm	UA915
Hose 32mm 1.2m	KC350
Bent hand piece 32mm	KC330
Two piece wand 32mm	KC9092
Crevice tool 32mm	KC911
Combination floor tool with wheels 32mm x 285mm	UA908W
Dusting brush 32mm	KC910
Upholstery tool 32mm	KC912
	Bolt 5x20 Nut 5mm nyloc Washer 3/16 x 3/4 N/A Washer 3/16 x 7/16 Carrying frame Shoulder strap pair Cord restraint Back support padding Hose complete 32mm 1.2m Machine end connector 32mm Hose clip ring 32mm Hose clip ring 32mm Hose 32mm 1.2m Bent hand piece 32mm Two piece wand 32mm Crevice tool 32mm Combination floor tool with wheels 32mm x 285mm Dusting brush 32mm

Technical specifications, part numbers and parts profiles are subject to change without notice.

Optional Extras Part No. KC909 Part No. KC928 Powerhead set complete Wand telescopic Part No. UA908 Part No. UA9272 Part No. UA917H Combination floor tool Bottom plate All purpose floor tool (suits combination floor tool Part No. UP112PB Part No. UA925WES Part No. UA913M RCD Piggy back Turbo head Bent hand piece metal



Service & Help

For service and help contact Pacvac on +61 8 9479 1444 or email support@pacvac.com

Alternatively visit our website at www.pacvac.com for a list of your nearest Retailers and Service Centres.