

## **DAILY MAINTENANCE CHART**

NTTB1840DMVNo1

## NUMATIC TWINTEC BATTERY

TTB1840

AFTER EVERY USE, ENSURE THAT YOU COMPLETE THE FOLLOWING 6 STEPS



1.



Empty the recovery tank and rinse thoroughly with clean water.

2.




Clean out the debris filter basket located under the seperator hood.

3-

Ensure the seperator seal is clean and undamaged. Replace if necessary.







**IMPORTANT:** Clean underside of squegee from dirt and debris.





Plug the battery in for charging.



## **WEEKLY MAINTENANCE CHART**


ITTB1840WMVNo

## NUMATIC TWINTEC BATTERY TTB1840

AFTER EVERY WEEK, ENSURE

THAT YOU COMPLETE THE FOLLOWING 4 STEPS





Check all 3 hoses for damage, holes and obstructions.



Thoroughly clean top seperator hood, filter, basket and seal.



Remove squegee and check for wear and damage. Clean thoroughly.



Remove brushes/pad drives and check for wear and damage.

