
Numado






NUC244NX

COMPACT SCRUBBER DRYER





Original Instructions

CAUTION, Read instructions before using the machine





COMPACT SCRUBBER DRYER

NUC244NX

Index


Machine Overview		Pages 1 & 2
Control Panel Overview	,	Page 3
Quick Set up Guide		Page 4
Brush fitting		Page 4
Main tank assembly remo	oval	Page 4
Clean water tank remova	I & filling	Page 5
Battery fitting & water flow	v setting	Page 6-7
Machine handle operation	n	Page 7
Storage & Transportation		Page 8
Regular maintenance		Page 9
Separator removal & clea	aning	Page 9
Clean water tank outlet cl	leaning	Page 9
Float valve removal & cle	aning	Page 10
Emptying Tanks		Page 10
Changing the floor-tool	blades	Page 11
Refitting the floor-tool bla	des	Page 11
Battery removal & charg	ging	Page 12
Removing the battery		Page 12
Battery Charging		Page 12
Twintec Maintenance		Page 12
Specifications		Page 13
Troubleshooting		Page 13
Rating Label / Personal Recycling	Protective Equipmen	
Safety Precautions		Page 15
Recommended Spare Pa	ırts	Page 16
Schematic Diagram		Page 16
EU Declaration Documen	ıt	Page 17
Warranty		Page 18
Company Address		Page 19

PLEASE READ BEFORE COMMENCING OPERATION. KEEP FOR FUTURE REFERENCE

After the removal of all the packaging, carefully open and check the contents

- Owner Manual
- Battery Charger & Lead
- Battery Pack Scrub Brushes x 2
 - Squeegee Assembly


	Machine Overview
1	Operator control panel
2	Triggers
3	Waste-water tank
4	Clean-water tank
5	Brush deck
6	Squeegee blades
7	Clean water flow adjustment taps
8	Clean-water filling / emptying cap
9	Floor-tool vacuum hose
10	Vacuum hose
11	Separator
12	Battery
13	Battery charger
14	Clean tank fill view windows
15	Storage lever
16	Floor-tool release lever
17	Transport / Storage wheels



COMPACT SCRUBBER DRYER

NUC244NX

Control Panel Overview



1	Battery Charge Level Meter
2	Vacuum On / Off
3	Water Flow On / Off
4	Triggers
5	Handle Lock Button (In the upright position)
6	Handle Release Lever
7	Start Button

In the event of a breakdown contact your Numatic dealer or the Numatic Technical help line +44 (0)1460 269268




PLEASE READ BEFORE COMMENCING ANY OPERATION. AFTER THE REMOVAL OF ALL THE PACKAGING, CAREFULLY OPEN AND CHECK THE CONTENTS.




NUC244NX CONTENTS

- Owner Manual
- Battery Charger & Lead
 - Battery Pack
 - Scrub Brushes x 2
 - Squeegee Assembly




Make sure the handle is locked in upright position and storage wheels are retracted. Remove the tank assembly (and battery if fitted) gently lay machine on its front

Brush fitting - Make sure battery is removed before fitting or removing brushes.





Push the brush / pad holder onto the brush motor mounts (1 & 2). Note: Gloves are recommended to be worn whilst fitting and removing the brushes.




To remove the brushes, place your fingers behind the brush deck in locations shown and gently wiggle off.

Floor tool and vacuum hose fitting






Push the floor tool carrier handle down and push the floor tool onto the retaining clips (1 & 2).




Take the hose and fit it into the hose retaining clips then push the open end securely over the centre fitting on the floor tool. Follow the arrows for the correct fit. Make sure part (A) of the hose stays loose and is not over stretched.


Main tank assembly removal



Remove the tank assembly from the front of the machine. Using the inset handle on the front of the tank assembly (A), lift the tank assembly up towards the main handle.




Lift and tilt the top of the tank assembly away from the handle as you remove. Place the tank assembly on a suitable surface in its upright/uppermost position.




Quick Set-up Guide


Clean water tank removal and filling




After lifting onto a suitable work surface, tilt the tank assembly slightly forward and slide your hand under the tank.





Slide your hand under the tank and curl your fingers up in the space in front of the tank, use your fingers to pop the tank out.




Remove the clean water tank from the main body of the tank holder.









Remove the clean water tank from the main body of the tank holder (4&5). To fill remove the rubber stop from the filling neck. Note: There is a T piece keeping the rubber stop from being completely removed.









Pour in the chemical (follow chemical manufactures dilution rates). Only fill the tank to the MAX fill line with clean water using a tap, hose or suitable water container. DO NOT OVER FILL. Slide the tank back into the main tank body, make sure the front of the clean water tank is lifted to enter the recess (A). Push the tank all the way in until you hear it click, make sure it is securely fitted before fitting the tank assembly back on the machine.


Quick Set-up Guide

Battery fitting and Water flow setting







Lift the battery using the battery handle. Place the battery into the battery compartment ensuring it is securely in place and the orientation is correct (battery handle folds down towards the machine handle (A)).




Refit the main tank onto the machine.




Tilt the bottom of the tank towards the handle above the battery.




Line the tank up against the machine handle and lower the tank down. Make sure it is securely fitted.



Clean water tank full and fitted to the machine.





Located on the left and right side of the machine are the individual water taps for each brush.




Push the fluid control levers on the Left and Right of the machine to set the desired flow required, this will vary depending on what brush / pad and floor type the machine is being used on. *Note: On first use open the water taps fully and run the machine for a short period to purge the water flow then adjust taps to desired flow. Make sure each lever is set to the same position.*


Quick Set-up Guide









To lower the machine deck to the ground. Stand behind the machine, grip the handles. With your right foot push the right pedal forward (11-B). (By pushing lever the front support wheel retracts under the deck (11-C)). Pull the small lever on the right hand side of the handle upwards (12-D) and then pull the handle backwards. To raise the floor-tool (for over-scrubbing without picking up water) use the toecap locations to the rear of the floor-tool (E or F).




Machine handle operation



To start the machine pull one or both triggers in and press the start button with the deck down, this will start the brushes spinning and the battery power indicator will illuminate to show the power level.




With either trigger pulled in press the water on button, this lights up blue to indicate it is on.




Press the vacuum on button, this lights up blue to indicate it is on and the vacuum starts. You are now ready to start cleaning.


Storage and Transport




Make sure the handle is in the upright position and locked in place, push the handle lock button and locate handle in correct position.

Storage and Transport mode option 1










To put the machine into storage mode start with the handle locked in the upright position and the floor-tool down (1), pull the handle backwards until the floor-tool moves up and the transport wheels click out into position the front support wheel is deployed (2). Rest the machine back onto the transport wheels (3) (no button or lever action is required). Note: Do not let go of the handle.

Storage and Transport mode option 2







To raise the floor-tool use the toecap locations to the rear of the floor-tool and lift up (A). To raise the machine deck off the ground. Stand behind the machine, grip the handle. With your right foot push the right pedal down (B) while pulling the machine backwards until the storage wheels click into position and the front support wheel extends.




MAKE SURE THE HANDLE IS LOCKED IN THE UPRIGHT POSITION BEFORE LETTING GO OF THE HANDLE.




Regular Maintenance


Separator removal and cleaning




Using thumb and index finger grip the tab of the separator and pull forwards.




Lift the separator away from the tank.




Take the separator to a suitable cleaning station.







Once the separator has been removed, wash thoroughly under a tap making sure to run water through the tubes and to clean the grid filter (A). Once clean thoroughly check the rubber seal for any damage or cracks (B). If any damage or cracks are found on the rubber seal replace the separator. Failure to replace could cause loss in suction and machine performance.

Clean water tank outlets






Remove the clean water outlets from the clean water tank.




Wash the clean water outlets thoroughly under a tap, make sure the filter is clean with no blockages. Check for any damage (if any damage is found replace the clean water outlets).


Float valve removal and cleaning




To remove the float valve twist the red retainer clip in the direction shown by the arrow on the retainer clip.





Lift the float valve from the tank, wash and inspect for damage.



Place the float valve back down into the tank.








Tilt forwards at a slight angle making sure the protruding nub fits into the recess on the float valve (B). Press down firmly on the arrow and the float valve will click into place.





WARNING! DO NOT PULL ON THE FLOAT BALL (A) PULLING ON THE FLOAT BALL WILL CAUSE IT TO BREAK AND THE VACUUM SHUT OFF WILL FAIL.





Emptying Tanks






When finished using the machine it is good practise to empty and clean the tanks of the machine. To do this firstly remove the tank assembly from the machine (see set up),

- 1. Remove the clean water tank from the main tank body and empty.
- 2. Remove the separator from the tank.
- 3. Pick up the tank, use the base shown as a handle, tip the contents into a suitable drain, rinse the tanks and repeat the emptying process. Refit the clean water tank and separator and place back onto the machine.

Note: If the machine is to be left for long periods between use, ensure the clean water tank is emptied.





Changing the Floor Tool Blades



Always make sure that the machine is switched off and the battery is removed prior to any maintenance.









To change the floor-tool, firstly lower the floor-tool using the left side floor-tool lowering foot pedal (A).


Pull the floor-tool away from the machine (B).




Unscrew the two knobs securing the blade holder (1).



Remove the blade holder (2).




Replace the Squeegee blades using (903531) replacement blade set (Fig.3), fitting the blades on to the moulded location lugs.



Refitting the Floor Tool Blades

Refit the blade holder, retain using the two outer knobs. Make sure the slotted blade goes to the front of the floor-tool.


Refit the floor-tool using the two central knobs to the floor-tool. Make sure the end holes on both squeegee blades are positioned correctly on 'T' shaped clip mouldings! (A)



Floor Tool Overview


- 1. Retaining knobs x 2
- 2. Front blade (Slotted / Reversible)
 - 3. Blade carrier
 - 4. Rear blade
 - 5. Floor tool main body


NOTE: The blades are designed to be reversible and rotated giving 4 usable surfaces (front, back, top and bottom, thus extending their useful working life).




Battery removal and charging

Removing The Battery







Remove the tank assembly from the front of the machine using the inset handle on the front of the tank assembly, lift the tank assembly straight up (A). Pull the tank assembly from the machine and place on the ground.

The battery can then be lifted from the machine for storage or charging using the handle on the battery (B).

For information relating to the operation and charging of your battery please refer to the battery and charger original operating instructions.

Daily Keep the machine clean.

Ensure brushes / pads / squeegee / filters are in good condition. Check for any worn or damaged parts and replace immediately. Drain and rinse dirty water tank after every use.

Weekly – as daily and – Check brush / pad and deck skirt, wipe and rinse. Check floor tool blades for wear and wipe clean.

Clean separator assembly including filter and check condition of seal.

Flush out system with clean water and clean filters.

Maintenance

Notes:			

Specifications

Model - NUC244NX					
Brush / Pad Weight in cleaning mode	Brush / Pad Pressure in cleaning mode	Cleaning Area	Brush Motor Power	Brush Speed	Brush / Pad Width
12.5 kg	Brush 18.95 g/cm ² Pad 20.10 g/cm ²	1320 m ² /Hour @ 3 km/h	2 x 200W	140 rpm	2 x 220mm (440mm)

Vac Motor Max Power	Clean Tank Capacity	Waste Tank Capacity	Water Ingress	Gross Weight (With liquid & battery)	Nett Weight (No liquid & No battery)	Rating
100W	2.2 L	3 L	IPX3	25.5 kg	21.3 kg	500W

*Run Time (Battery life)	*Recharge Time	Dimensions	Hand Arm Vibration	Sound Pressure
*60-80 Min	*1 Hour (80%) *2 Hours (100%)	Width = 520 mm Length = 450 mm Height = 1200 mm	≤ 2.5 m/s²	LpA ≤ 70 dB(A)

^{*}Run and Recharge times may vary dependent on ambient temperature.


Troubleshooting

PROBLEM	CAUSE	SOLUTION
Machine will not operate	Battery not connected	Connect battery (page 6)
	Low battery charge	Charge battery (page 12)
Vacuum will not operate	Vacuum not turned on	Turn on vacuum (page 7)
Poor water pick-up	Waste-water tank full	Empty waste-water tank (page 10)
	Clogged / blocked squeegee hose	Remove and clean (page 4)
	Loose hose connections	Push tight connections (page 4)
	Separator filter clogged / blocked	Clean (page 9)
	Poor separator seal	Clean and refit (page 9)
	Damaged separator seal	Renew (Spare parts page 16)
	Damaged / split vacuum hose	Renew (Spare parts page 16)
	Damaged floor-tool blades	Renew (Spare parts page 16)
	Low battery charge	Recharge battery - see battery charger manual
No brush / scrub function	No brushes fitted	Check and fit (page 4)
	Brush overloaded	Reset the machine and decrease the brush load
Little or no water flow	Clean-water tank empty	Fill clean-water tank (page 5)
	Incorrect water flow setting	Adjust fluid control levers (page 6)
	Blocked clean water tank outlets	Remove and clean (page 9)

Failure to rectify the problem or in the event of a breakdown contact your Numatic dealer or Numatic Technical helpline +44 (0)1460 269268

About the Machine

Rating L	Rating Label			
1	Company Name & Address			
2	Machine Description			
3	Battery Voltage			
4	Noise Emission			
5	Hand Arm Vibration			
6	Weight (ready to use)			
7	Ingress Protection Rating			
8	Gradient symbol			
9	EU Importers info			
10	Battery part number			
11	Machine QR code			
12	Approvals Mark			
13	WEEE symbol			
14	Part Number			
15	Machine yr/wk Serial number			
16	Numatic Support			



WEEE (Waste, Electrical and Electronic Equipment)

Scrubber dryer Accessories and packaging should be sorted for environmentally-friendly recycling. Only for EU countries.

Do not dispose of scrubber-dryer into household waste.

According to the European Directive 2012/19/EU on waste electrical electronic equipment and its incorporation into national law. Scrubber-dryers that are no longer suitable for use must be separated, collected and sent for recovery in an environmentally-friendly manner.



PPE (Personal protective equipment) that may be required for certain operations.



NOTE: A risk assessment should be conducted to determine which PPE should be worn.

Safety Critical Component:

Charging Leads: HO5VV-F x 0.75mm² x 3 CORE Battery Charger: 100 - 240 Volt In the event of a breakdown contact your Numatic dealer or the Numatic Technical help line +44 (0)1460 269268

Information for Scrubber Dryer

COMPONENT	INTERVAL	INSPECT FOR
Mains Lead	DAILY	Scuffing, cracks, splits, conductors showing
Brushes	DAILY	Bristle damage, wear, drive collar wear
Squeegee Blade	BEFORE EACH USE	Wear, cracks, splits
Filters	BEFORE EACH USE	Clogging and debris retention
Tanks	AFTER EACH USE	Rinse dirty water tank after use



As with all electrical equipment care and attention must be exercised at all times during its use, in addition to ensuring that routine and preventative maintenance is carried out periodically in order to ensure its safe operation. Operators shall be adequately instructed as to the correct use of the machine.

Failure to carry out maintenance as necessary, including the replacement of parts to the correct standard could render this equipment unsafe and the manufacturer can accept no responsibility or liability in this respect. When ordering spare parts always quote the Model Number / Serial Number specified on the Rating Plate. Warning do not use on slopes exceeding 2%.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, Children should be supervised to ensure that they do not play with the appliance.

Only use brushes provided with the appliance or those specified in the instruction manual.

The use of other brushes may impair safety.

A full range of brushes and accessories are available for this product.

Only use brushes or pads which are suitable for the correct operation of the machine for the specific task being performed.

It is essential that this equipment is correctly assembled and operated in accordance with current safety regulations.

When using the equipment always ensure that all necessary precautions are taken to guarantee the safety of the operator and any other persons who may be affected.

Wear non slip footwear when scrubbing. Use a respiratory mask in dusty environments.

When cleaning, servicing or maintaining the machine, replacing parts or converting to another function the battery should be removed.

Machines left unattended shall be secured against unintentional movement. When detergents or other liquids are used, read the manufacturer's instructions.



This machine is not suitable for picking-up hazardous dust. The machine is not to be stored outdoors in wet conditions. This machine is for indoor use only.

NOTES: This machine is intended for commercial use, for example in hotels, schools, hospitals, factories, shops and offices for other than normal housekeeping purposes. This product meets the requirements of IEC 60335-2-72



- Ensure only competent persons unpack / assemble the machine.
- Keep your machine clean.
- Keep your brushes in good condition.
- Replace any worn or damaged parts immediately.
- Ensure that the work area is clear of obstructions and / or people.
- Ensure that the working area is well illuminated. Pre-sweep the area to be cleaned.




- Use steam cleaners or pressure washers to clean the machine or use in the rain.
- Allow any inexperienced repairs. Call the experts.
- Allow the machine to be used by inexperienced or unauthorised operators or without appropriate training.
- Use the machine without the solution tanks properly positioned on the machine, as shown in the instructions.
- Expect the machine to provide trouble-free, reliable operation unless maintained correctly.
- Run the machine over power cable during operation.
- Lift or pull the machine by any of the operating triggers, use the main handle.

Spare Parts

Part No.	SPARES & ACCESSORIES	Part No.	SPARES & ACCESSORIES
909996	BATTERY	911798	BALL SHUT OFF ASSEMBLY
911334	LITHIUM BATTERY CHARGER	911502	SEPARATOR MOULDING & SEAL OVER MOULD
912365	CHARGER CABLE (UK)	911931	NYLO SCRUB BRUSH SET PACK OF 2
912361	CHARGER CABLE (EURO)	912353	RED PADS PACK OF 10
912364	CHARGER CABLE (SWISS)	912354	WHITE PADS PACK OF 10
912363	CHARGER CABLE (SOUTH AFRICAN)	912352	GREEN PADS PACK OF 10
912360	CHARGER CABLE (AUSTRALIAN)	912356	MELAMINE PADS PACK OF 2
912362	CHARGER CABLE (NORTH AMERICAN)	912355	DIAMOND PADS PACK OF 2
911518	SERILOR BLADE SET (FRONT)	911844	DRIVE BOARD PACK OF 2
911519	SERILOR BLADE SET (BACK)	911500	CLEAN WATER TANK
		911499	WASTE WATER TANK

Schematic Diagram



Lithium-Ion Battery Warranty

Warranty: Commercial Use

- a. Batteries are warranted (1 Year) providing all battery care rules are followed
- b. To claim warranty the following details must be supplied
- i. Serial number of the machine
- ii. Battery date code
- iii. Date purchased
- iv. Proof of Purchase
- v. Maintenance history and charging regime

Failure to use the correct Numatic charger will void your warranty.

Warranty Numatic International

Numatic International Limited warrant to the original purchaser that its products are free of defects in both material or workmanship for the period shown below:-

Homecare and Cleancare Vacuum cleaners	2 Years
Rotary Floor Machines	2 Years
Twintec Auto Scrubber Dryer	. 1 Year
Vario Ride-On Scrubber Dryer 1 Year / 15	00 hours
Mopping, Compacts, Combi and Servocare Products	1 Year
Individual Accessories and Spare Parts	6 Months

Note: This warranty expressly excludes consumable parts such as carbon brushes, floor brushes, mops, batteries etc, that are considered replaceable from time to time during the normal working life of the machine.

- A. The warranty period commences from the date the goods are purchased.
- B. All warranty claims must be processed through the Dealer from whom the equipment was purchased. The Dealer will co-operate with the purchaser throughout the warranty claims procedure and will arrange any necessary repairs using genuine Numatic parts.
- C. If the original Dealer is no longer able to fulfil his obligations please contact Numatic International Limited with full details of the claim and proof of purchase so that this may be processed without delay.
- D. Any warranty claim can only relate to the specific part that is proven to be at fault and for which a replacement will be supplied but cannot be extended to constitute a claim against the complete machine.
- E. Numatic International will supply the Dealer with any warranty parts required, subject to the claim being validated, after return of the faulty items in accordance with Numatic International Limited's General Conditions of Sale.
- F. Claims will not be accepted if they are the result of fair wear and tear, misuse or abuse of any kind.
- G. No replacement will be given unless the appropriate evidence of the validity of the claim has been provided to the satisfaction of Numatic International Limited.
- H. Numatic International Limited reserve the right to charge for any unnecessary work carried out as a result of an invalid claim.
- I. No variation to this warranty may be made or implied by any member of Numatic International Limited or its Dealers unless such variation is in writing and authorised by the Company

Numatic International Limited. Chard, Somerset, TA20 2GB Telephone: 01460 68600 Fax: 01460 68458

© Numatic International Limited

		Numatic International Limited
Manufacturer:	Numatic II Chard Somerset TA20 2GB www.num	Chard Somerset TA20 2GB www.numatic.co.uk
Product:	TTB24	TTB244, NUC244
Description:	Floor	Floor Treatment - Walk Behind – Commercial - Battery
We, Numatic hereby declare under our sole responsibility, in conformity with the following directives and standards.	directives and sta	We, Numatic hereby declare under our sole responsibility, that the above-mentioned product(s) is/are in conformity with the following directives and standards.
	Machinery Regulations	EN60335-2-72:2012 EN62233:2008
S.I. 2016: 1091	EMC Regulations	EN55014-1:2017 + A11:2020 EN55014-2:1997 + A1:2001 + A2:2008
S.I. 2012: 3032	RoHS Regulations	
Authorised Signatory: Mr. Matthew Coles	thew Coles	Position: Head of Technology
Signed: M. Colon D	Date: 1 st Dec 2021	Numatic International Limited, Chard, Somerset, TA20 2GB, UK

Floor Treatment – Walk Behind – Commercial - Battery

Deklaracja zgodności Declaratie de conformitate Alexnapatuna o coorretcranu Försäkran om överensstämmelse Izjava o skladnosti Vaatimustenmukaisuusvakuutus

> Δήλωση συμμόρφωσης Megieleiőségi nylatkozat Dichiarazione di conformità Attitkites deklaracija Conformiteitsverklaring Samxarserklæring Samxarserklæring Declaração de conformidade

EU, EC, EL, UE, ES:
Declaration of Conformity
Prohlášení o shodě
Konformitätseklárung
Overensstemmelseserklæring

Declaración de conformidad Vastavusdeklaratsioon Déclaration de conformité

Декларация за съответствие

Numatic International Limited

www.numatic.co.uk TTB244, NUC244

Chard Somerset TA20 2GB

Manufacturer: / Wyrobce / Hersteller / Fabrikant / Fabricante / Tootja / Fabricant / npovasogurenb / Koxtoxeeucorty(, Gystof / Fabricante / Gamintojas / Fabrikant / Produsent / Fabricante / Producent / Producen

Product: / Produkt / Produkt / Producto, Toodet, Produit/ Προдукт / Προΐον / Termék / Prodotto / Produktas / Artikel / Produkt / Produtos / Produkt / Produs / Το8ap / Produkt / Izdelka / Tuote:

Description: / Popis / Beschreibung / Beskrivelse / Descripción / Kirjeldus / La description / Οπυсание / Περιγραφή / Leirás / Descrizione / Apibudinimas / Omschrijving / Beskrivelse / Descrição /

Opis / Descriere / Описание / Beskrivning / Opis / Kuvaus:

Opis / Descriere / Описание / Beskrivning / Opis / Kuvaus:	ning / Opis / Kuvaus:	
GB We, Numatic hereby declare under our	our BG ние, Numatic C настоящото	PT Nós, a Numatic declaramos, sob nossa
cole reconcibility that the above-		
montioned and under in fact in conformity		
mentioned product(s) is/ are in conformity	че посочените по-горе продукты е в	acima mencionado esta em comormidade
with the following directives and standar		com as anethres e normas a seguir.
CZ My, Numatic prohlašujeme na svou	стандарти.	PLMy, Numatic Niniejszym oświadczamy z
výlučnou odpovědnost, že výše uvedený	GR Εμείς, Numatic δηλώνουμε με	pełną odpowiedzialnością, że wyżej
výrobek je ve shodě s následujícími	αποκλειστική μας ευθύνη, ότι το	wymieniony produkt jest zgodny z
směrnicemi a normami.	προαναφερόμενο προϊόν συμμορφώνεται	następującymi dyrektywami i normami.
DF Wir Numaticerklären in alleiniger	με τις ακόλουθες οδηγίες και πρότυπα.	RO Noi Numatic Prin prezenta declarăm
Verantwortung, dass das oben genannte	HU Mi, Numatic Kijelentjük, egyedüli	pe propria răspundere, că produsul mai sus
Produkt den folgenden Richtlinien und	felelősséggel, hogy a fent említett termék	mentionat este în conformitate cu
Normen entspricht.	megfelel az alábbi irányelveknek és	următoarele standarde și directive.
DK Vi, Numatic erklærer hermed under	szabványoknak	RU Ми, Нилфиск овим изјављујем под
eget ansvar at ovennævnte produkt(er) er i	i IT Noi, Numatic dichiara sotto la propria	пуном одговорношћу, да наведеног
overensstemmelse med følgende direktiver	-	
og standarder.	conforme alle seguenti direttive e norme.	директивама и стандардима.
ES Nosotros, Numatic declaramos bajo	LT Mes, "Numatic pareiškiu vienašališkos	SE Vi Numatic förklarar härmed under
nuestra única responsabilidad que el	atsakomybės, kad pirmiau minėtas	eget ansvar att ovan nämnda produkt
producto antes mencionado está en	produktas atitinka šias direktyvas ir	överensstämmer med följande direktiv och
conformidad con las siguientes directivas y	r standartus	normer.
normas	NL we verklaren Numatic hierbij op eigen	SI Mi, Numatic izjavljamo s polno
EE Meie, Numatic Käesolevaga kinnitame ja		
kanname ainuisikulist vastutust, et eespool	l bovengenoemde product voldoet aan de	izdelek v skladu z naslednjimi smernicami in
nimetatud toode on kooskõlas järgmiste	volgende richtlijnen en normen	standardi.
direktiivide ja	NO Vi, Numatic erklærer herved under	FI Me, Numatic täten vakuutamme omalla
FR Numatic déclare sous notre seule	aget answer at det ovennevnte produktet er	
responsabilité que le produit mentionné ci-		
dessus est conforme aux directives et normes	i samsvar med røgende direktiver og nes standarder	standardien mukaisesti
suivantes.		
2006/42/EC	Machinery Directive EN60335-1:203 EN60335-2:203 EN62233:2008	EN60335-1:2012 + AC:2014 + A11:2014 + A13:2017 EN60335-2-72:2012 EN62233:2008
2014/30/EU	EMC Directive EN5501	EN55014-1:2017 + A11:2020
	EN5501	EN55014-2:1997 + A1:2001 + A2:2008
2011/65/EU	RoHS Directive	
Authorised Signatory: Mr. Matthew Coles	Coles	Position: Head of Technology
0		
		Numatic International Limited
		Chard,
100		
Signed: / C	Date: 04 th May 2022	Somerset, TA20 2GB, UK

This Machine Has Been Packed With The Following	Distributed by:	
Scrub Brush / Pad Squeegee Assembly Charger / Lead & Battery Pack		
	Мштала	



Numatic International Limited. Chard, Somerset TA20 2GB ENGLAND Tel: 01460 68600 www.numatic.co.uk



Numatic International GmbH. Fränkische Straße 15–19 D-30455 Hannover, DEUTSCHLAND Tel: 05 11 98 42 16 0 www.numatic.de



Numatic International SAS. 13 / 17 rue du Valengelier EAE La Tuilerie, 77500 CHELLES, FRANCE Tel: 01 64 72 61 61 www.numatic.fr



Numatic International BV, Vennootsweg 15 2404 CG, Alphen aan den Rijn, Nederland Tel: 0172 467 999 www.numatic.nl



Numatic International (Pty.) Ltd. 16th & Pharmaceutical Roads, Midrand, Gauteng, SOUTH AFRICA 1685 Tel: 0861 686 284 www.numatic.co.za



Numatic International Schweiz AG. Sihlbruggstrasse 3A, 6340 Baar. SCHWEIZ Tel: 0041 (0) 41 76 80 76 - 0 www.numatic.ch



Numatic International ULDA. Rua da Boa Viagem, 177 4470.210 Maia. PORTUGAL Tel: +351 220 047 700 www.numatic.pt



Numatic International SLU. C/ La Forja, 41, 08840 Viladecans (Barcelona), Spain

Tel: +34 93 647 22 22 www.numatic.es

This Product has been comprehensively inspected and checked during every stage of its manufacture.

Including an in-depth electrical safety and functionality test.

Specification subject to change without prior notice numatic.com © Numatic International Limited